

Installing and Using the Magtek MICR Mini Check Reader



Cash Register Express or Restaurant Pro Express is now compatible with the Magtek MICR Mini Check Reader. This document details how to connect all the hardware and install the necessary drivers.

Installing the MAGTEK Check Reader Drivers



To process Check transactions the Magtek Check Reader (P/N: **22523009**) must be installed.

The Driver for this device can be downloaded from:

- http://download2.pcamerica.com/drivers/Manufacturer/MAGTEK/MAGTEK_Mini_MI_CR.zip

Note: The above file contains drivers for both 32 and 64 bit operating systems.

When installing the above files in Windows 7 make sure to right-click and select Run as Administrator on the installation file (DPInst.exe).

	<p>1. Select Next.</p>						
 <table border="1" data-bbox="435 1549 841 1654"><thead><tr><th>Driver Name</th><th>Status</th></tr></thead><tbody><tr><td>✓ MAGTEK USB (11/10/2...</td><td>Ready to use</td></tr><tr><td>✓ MagTek (MTIMUSB) Por...</td><td>Ready to use</td></tr></tbody></table> At the bottom are buttons for '< Back', 'Finish', and 'Cancel'.	Driver Name	Status	✓ MAGTEK USB (11/10/2...	Ready to use	✓ MagTek (MTIMUSB) Por...	Ready to use	<p>2. Select Finish.</p>
Driver Name	Status						
✓ MAGTEK USB (11/10/2...	Ready to use						
✓ MagTek (MTIMUSB) Por...	Ready to use						

Connecting the Magtek Check Reader



1. In order to connect the device you will need the following cables:
 - The USB cable (P/N:**22517583 REV.B**).
 - The Power cable (MODEL NO.: **AA-121A**).



2. Connect the round end of the USB cable to the port on the check reader, connect the other end of that cable to an available USB port on your computer.
3. Connect the Power cable to the check reader and then the other end of that cable to a power outlet.

Testing the Magtek Check Reader

Open Notepad.exe and swipe the check through the reader as pictured below:



The MICR should be facing inward and on the bottom of the page.